



## KeyWin6

### User guide

## INDEX

---

### KeyWin6 Manual

- 3 Login
- 4 Administration
- 5 User - Basic
- 6 User - Advanced
- 7 Groups
- 8 Keys - Basic
- 9 Keys - Advanced
- 10 Connect Users & Keys via Group
- 11 Connect Users & Keys directly
- 12 Event log
- 13 Reports
- 14 Booking
- 15 Settings
- 16 Cabinet Overview
- 17 Add new cabinet
- 18 Edit cabinet - Basic
- 19 Edit cabinet – Advanced
- 20 Settings administrator
- 22 Import/Export
- 23 Advanced Settings
- 24 Product information
- 25 Integrations
- 26 Notifications


## LOGIN

---

Go to this address to login: <https://www.keywin.app/portal/login>

Site name and admin password should have been provided by your dealer or by Creone.


If you are missing your site name and admin password please send a request to [support@creone.com](mailto:support@creone.com).



The image shows a screenshot of the KeyWin6 login interface. At the top, the text 'KEYWIN6' is displayed in a bold, blue, sans-serif font. Below this, the title 'KeyWin Login' is centered in a white, sans-serif font. A small instruction in white text reads: 'Please enter your site name and KeyWin administrator password that you use to sign in to your KeyWin account.' There are two white input fields with rounded corners. The first field is labeled 'Site name' and the second is labeled 'Admin password'. Below the 'Admin password' field, there is a checkbox labeled 'Remember me' and a link that says 'Forgot password?'. In the bottom right corner of the login box, there is a white button labeled 'Login'.

## ADMINISTRATION

In **ADMINISTRATION** you will get an overview of **USERS**, **GROUPS** and **KEYS**.

You use  to add, remove or edit values. The plus, minus and edit pen are functions that are used all through the Keywin 6 portal.

In the search field you can search for any information, the best match will be shown.

Administration

+

-

USERS

+

-

GROUPS

Key overview

-

KEYS

...

Fredrik Boberg

Michael Gustavsson

...

TEAM BRAVO

team alpha

To connect state

...

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key001

Key002

Key002

Key002

Key002

Key002

Key002

Key002

Key002


Key002

Key002

☐ Show taken keys only

## ADMINISTRATION – ANVÄNDARE


To **CREATE** a new user press the + on the left side next to **USERS** on the **ADMINISTRATION** page.

The plus,  minus and editing pen are re-occurring functions that you use for to add, delete or edit values all through the portal.

User settings are divided by **BASIC** settings and **ADVANCED** settings.

### BASIC

<b>User Name</b>	Create a unique user name
<b>First name</b>	Add the users first name
<b>Last name</b>	Add the users last name
<b>Active</b>	Check if user is active/de-activated
<b>Language</b>	Choose the language the user wants the keybox to communicate with.
<b>Pin code</b>	Chose the pin code for the keybox
<b>External reader</b>	If the user rather use card(s)/badge(s) to log-in, enter the id number here and fill in the check-box under "Use third-part authentication"
<b>Hexadecimal</b>	Uses letters and digits as a third party reader code
<b>Decimal</b>	Uses only digits as a third party reader code




## ADMINISTRATION – USER - ADVANCED

---

### ADVANCED

<b>E-mail</b>	Enter users e-mail
<b>User type</b>	Enter user type. Normal user is default. If you set the Non-trusted user, this user needs to be confirmed by an "trusted user" for each opening of the cabinet. The confirmation is to enter a trusted users pin code.
<b>Cellphone/Phone</b>	Enter the users cellphone or phone. Note that cellphone will appear in the cabinet display in case this user have taken a key.
<b>Service</b>	Enter the service of the user.
<b>Department</b>	Enter the department of the users. This is also searchable in the administration
<b>Valid from-to</b>	Here you can set a date frame for when the user is valid.
<b>Comment*</b>	Here you can enter any additional information needed.

\*Beware of your company's GDPR policy when using comments and personal information.


Add new user

BasicAdvanced

Email

User type

☒ Normal user
☐ Trusted user
☐ Non-trusted user

Cellphone

Phone

Service

Department

Valid from

2021-02-22

X

Valid to

9999-12-31

X


Comment

CancelSave

## ADMINISTRATION – GROUPS

To **ADD** a new **GROUP** press on + on the left side of **GROUPS** under **ADMINISTRATION**. You will then see the menu below.

Enter a name for the **GROUP** and chose the time channel when the group shall be valid (access for the users to the keys) and if there are any other comments\*.

 Add new group

Group name  
  
Name that will be visible in the administration view

Comment

☐ Use time channel

About groups

With groups it becomes easier to manage many people with different access. It's possible to create both key groups as well as user groups.

Limit a groups usage by turning on time channel. The groups keys will only be available when the time channel is active.

All	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Monday																								
Tuesday																								
Wednesday																								
Thursday																								
Friday																								
Saturday																								
Sunday																								

Cancel

Save

\*Beware of your company's GDPR policy when using comments.

## ADMINISTRATION – KEYS

---

The Keys can't be added from the portal. You need to login to the cabinet with the administration PIN-code and insert each intellipin one by one, when that have been done, the key will automatically appear in KeyWin6 key administration. The keys will automatically be named "Key001", "Key002" etc.

Highlight the key and press on **EDIT** to see following:

The KEY-settings are divided by **BASIC** and **ADVANCED**.

### BASIC

<b>Name</b>	Enter the name the key shall have in the system
<b>Key-ID</b>	For each key or group of keys you can enter a Key-ID. E.g. for all car-keys you can use "CAR" as a Key-ID. Then you can search for "CAR" and all your car keys will appear. The settings in Key-ID does not affect the position of the keys physical location in the cabinet.
<b>Color</b>	Since we can offer keyrings in different color you can also colorize the keys in the software.



## ADMINISTRATION – KEYS - ADVANCED

### ADVANCED

<b>Time limit</b>	Set the time the key can be out of the cabinet. If the key is not returned to the system within the time frame, the cabinet will register an alarm.
<b>Comment*</b>	Enter your own comment of the key.
<b>Available cabinets</b>	The key will automatically be set to be allowed in the cabinet where the key first was registered. If you need to be able to return the key in another cabinet you need to specify what more cabinet the key should be allowed in.
<b>Use locked key position</b>	When using a fixed key position it means that you force the users to return the key at the same position as it was picked up. If the user return it to another position the cabinet will create an alarm and show where the key shall be returned. <b>Please note that this feature cannot be used together with allowing "Keys in multiple cabinets"</b>

\*Beware of your company's GDPR policy when using comments.

**Edit key** Basic **Advanced**

Days: 0 Hours: 0

Minutes: 0

Comment:   
Max. length 5000

Available cabinets:   
Changes in this list will take effect immediately

- 4 listers keyrack (green checkmark)
- Förvaltning - Dörr 2 (red X)





☐ Use locked key position

Cabinet:   
Door:   
List:   
Position:


Cancel Save

## ADMINISTRATION – CONNECT USERS & KEYS VIA GROUP

To connect **USERS** and **KEYS** via a **GROUP**, do as following:

- 1. Highlight the group you like to use
- 2. Click on **TO CONNECT STATE**
- 3. Now you will see all users and keys in your system with  or .
- Click on  and when it change to  the connection is complete.
- When you are done, click on **TO SEARCH** to return to search-view.
- For more or new connections, repeat procedure above.





 Administration



The screenshot displays the CREONE Administration interface with three main sections: **USERS**, **GROUPS**, and **KEYS**. The **GROUPS** section is currently active, showing a list of groups. A green circle with the number '1' highlights the 'UTV' group. Below the groups list, a blue button labeled 'To search' with a green circle and the number '2' is highlighted. The **USERS** section on the left shows a list of users, with 'Nicklaz Eneroth' having a green checkmark icon. The **KEYS** section on the right shows a list of keys, with '9400sc001' having a green circle with the number '3' and a red X icon next to it. A checkbox labeled 'Show taken keys only' is visible at the bottom right of the keys list.

## ADMINISTRATION – CONNECT USERS & KEYS DIRECTLY WITHOUT GROUP

To connect a **USERS** or **KEYS** directly to each other, without any **GROUP**, do as following:

- Highlight the **USER** or **KEY** you like to use
- Click on **TO CONNECT STATE**
- Now you will see all users or keys in your system with  or . (In the example connection is done from USER to KEY) A Checkbox without circle indicates that the key has been connected via a group.
- Click on  and when it change to  the connection is complete.
- When you are done, click on **TO SEARCH** to return to search-view.
- For more or new connections, repeat procedure above.

### Administration

USERS

GROUPS

KEYS

Filter users...

Adam Bjellquist
Alexander Sverla
Dave1 Ghrol1
Dave10 Ghrol10
Dave100 Ghrol100
Dave101 Ghrol101
Dave102 Ghrol102
Dave103 Ghrol103
Dave104 Ghrol104
Dave105 Ghrol105
Dave106 Ghrol106
Dave107 Ghrol107
Dave108 Ghrol108
Dave109 Ghrol109
Dave11 Ghrol11
Dave110 Ghrol110

Filter groups...

TESTING KEYRACK + 1
9400sc demorum
9500sc Räddningstjänst
9500UTV DÖRR1
9500UTV DÖRR2
9600
All users
Entreprenad eftermiddag
Entreprenad förmiddag
Förvaltning
Hygientekniker
Johan utv keyrack
Keyrack Demorum
kuben 29-42
kuben 43-56
kuben list 1-8

Filter assets...

Demo001
Demo002
Demo003
räddningstjänst002
räddningstjänst003
9400sc001
9400sc002
9400sc003
9400sc004
9400sc005
9400sc006
9400sc007
9400sc008
9400sc009
9400sc010
9400sc011

☐ Show taken keys only

## EVENT LOG

In the event log you will see everything that happens in your system, both from cabinet and the portal.

In the **FILTER** tab you can search for a key or user to find more information. When clicking on the down-arrow, next to the filter-search field, you can filter on time-frame or specific event.

When pressing the printer symbol in the upper right corner, you can export your result.

When an alarm appears the event will be highlighted in red. Once the alarm is confirmed by you, you can press on **ACKNOWLEDGE ALL ALARM** (all alarms in the system will be acknowledge) or click on that specific alarm to only confirm that specific alarm.

KEYWIN6

Administration Eventlogs Reports Bookings Settings

Q Eventlogs

The log displays all the events, both from the keybox and from KeyWin

Filter..

Date	Time	User /Group	Cabinet	Key	Card number / PIN	Event
2018-03-01	13:58:15		keybox9400sc			Door closed
2018-03-01	13:58:12		keybox9400sc			Unauthorized door opened
2018-03-01	13:41:11	Christer Pettersson				User deleted
2018-03-01	13:41:03	asgfkias faskifaksf				User deleted
2018-03-01	09:47:44		keybox9400sc			User logged out
2018-03-01	09:47:44	Michael Gustavsson	keybox9400sc			Door closed
2018-03-01	09:47:39	Michael Gustavsson	keybox9400sc			Door opened
2018-03-01	09:47:37	Michael Gustavsson	keybox9400sc		PIN	User logged in
2018-03-01	09:47:32		keybox9400sc			Cabinet updated
2018-03-01	09:46:55	Michael Gustavsson				User changed
2018-03-01	09:46:40		keybox9400sc			Cabinet changed
2018-03-01	09:44:32		Keyrack			User logged out
2018-03-01	09:44:15	Michael Gustavsson	Keyrack		PIN	User logged in

Acknowledge all alarms

Updated 2018-03-01 14:01:32 Displaying 20 Events


## REPORTS

In the **REPORTS** tab you will find useful information of your system and how it's used by the users. Please note that the report module is still in the makings, once released see separate manual in Creone's Help center.

Here you will see a summary of how many **Groups**, **KEYS** and **KEYS OUT OF THE SYSTEM**

You can also see a diagram that will summary **Keys taken** and **Alarms** for each day. This statistic you can save by pressing **"SAVE REPORT"** (still under development)

Finally you will be able to see the **TOP 5/10 USERS & KEYS** used in your system



## BOOKING

Under the **BOOKINGS** tab you can make a reservation for a user and key with specific time-limitations.

### 🔍 Bookings

All key bookings can be configured here. All dates and times are displayed in local time on cabinet.

User	Key	Date from - to	Time from - to
Nicklaz Eneroth	räddningstjänst003	2017-06-30 - 2017-06-30	10:00 - 10:30
Nicklaz Eneroth	FörvaltningD1-001 Algatan 3-10	2017-10-02 - 2017-10-02	11:00 - 13:00
Nicklaz Eneroth	FörvaltningD1-002 Aspgatan	2017-10-02 - 2017-10-02	13:00 - 13:30
Pelle Bok	FörvaltningD1-003 Algatan	2017-10-02 - 2017-10-02	14:00 - 15:00
johan wärnelöv	Demo020	2018-02-09 - 2018-02-09	11:48 - 13:48

Press on + to add a new **BOOKING** and you will see the menu below:

Create a new booking

Key

Search key..

User

Search user..

Date from

Choose date

Date to

Choose date

Time from (local time on cabinet)

Choose time

Time to (local time on cabinet)

Choose time

Key unavailable before booking (min)

Choose time

Monday

26 Feb

Tuesday

27 Feb

Wednesday

28 Feb

Thursday

1 Mar

Friday

2 Mar

Saturday

3 Mar

Sunday

4 Mar

Cancel

Save

<b>KEY</b>	-	Select the KEY that shall be booked.
<b>USER</b>	-	Select the USER that shall use the KEY
<b>DATE FROM</b>	-	Select the date the user shall have access to the KEY
<b>DATE TO</b>	-	Select the end-date the user shall have access to the KEY
<b>TIME FROM</b>	-	Select the time the user shall have access to the KEY
<b>TIME TO</b>	-	Select the end-time the user shall have access to the KEY
<b>KEY UNAVAILABLE</b>	-	Here you can select time prior to the access for the user that the specific key shall be locked for other users to take.

## SETTINGS

Under **SETTINGS** tab you will see a menu to the left with following categories;

- Cabinet Overview
- Administrators
- Import/Export
- Advanced settings
- Product information
- Creone
- Integrations
- SMTP – OBS! Not in use.
- Notifications
- Other


[Support](#)
[English ▾](#)
[Logged in as: Admin Admin !\[\]\(279cd448dded2ade95bc3b6bc2ed243e\_img.jpg\)](#)

---

## KEYWIN6

[Administration](#)
[Eventlogs](#)
[Reports](#)
[Bookings](#)
[Settings](#)

---


Settings

Cabinet overview

Administrators

Import/Export

Advanced settings

Product information

Creone

Integrations

Smtip

Messages

Notifications

Other

Name	Location	Pairing code
Keyrack	Creone	7B733075
Keybox	Creone	7B73304B
Keybox 1		7B733E9E

## SETTINGS – CABINET OVERVIEW

Under **CABINET OVERVIEW** tab you will be able to add, remove and edit your cabinets.

You will also see a list of all your active cabinets with Name, Location and Pairing code.

To ADD a new cabinet, see next page.

[Support](#)    [English ▾](#)    Logged in as: Admin Admin

**KEYWIN6**

[Administration](#)    [Eventlogs](#)    [Reports](#)    [Bookings](#)    [Settings](#)

**Settings**

- Cabinet overview**
- Administrators
- Import/Export
- Advanced settings
- Product information
- Creone
- Integrations
- Smtip
- Messages
- Notifications
- Other

Name	Location	Pairing code
Keyrack	Creone	7B733075
Keybox	Creone	7B73304B
Keybox 1		7B733E9E



## SETTINGS – CABINET OVERVIEW – ADD NEW CABINET

### CABINET SETTINGS

1. Go to your Cabinet, enter 1234# on the Cabinet keypad, you will now enter the configuration menu. Move through the configuration menu using the arrows on the keypad, use # to open each menu and confirm each setting.
2. Go to “DHCP” Set DHCP to ON or OFF
3. Go to respectively “SET IP”, “NETMASK”, “GATEWAY” and “DNS” and enter the values according to your IT-departments recommendation.
4. Go to “Reboot”, restart the Cabinet to confirm your configuration setup

Once the cabinet is rebooted move to Keywin 6 portal, add a new cabinet and enter name off the cabinet and pairing code.

The cabinet will now appear as (not yet initialized). When KeyWin6 synched all the information to the cabinet, when the cabinet is ready the (not yet initialized) will disappear. When this is done, the cabinet has been registered correctly and you can continue your cabinet configuration.

Highlight the name of cabinet and press on EDIT. Go to next page for continuing the instructions.

Name	Location	Pairing code
Keyrack	Creone	7B733075
Keybox	Creone	7B73304B
Keybox 1 (not yet initialized)		7B733E9E

## SETTINGS – CABINET OVERVIEW – ADD NEW CABINET

---

Mark the cabinet in the cabinet view to start edit name and location etc.

### BASIC


**NAME:** The name you will see on the cabinet display

**LOCATION:** E.g. Office, reception

**LANGUAGE:** The language the cabinet shall use

**CARD READER:** The card reader the cabinet is using

**SERVICE PIN:** Default 1234#. Will give you access to the configuration menu.



**Edit cabinet**

**Basic** Advanced

**Name**

Keybox 1

Name that will be visible in the administration view

**Number of doors** **Number of lists**

1 2

**Location**

**Language** **Cardreader**

English

**Service pincode**

....

Cancel Save

## SETTINGS – CABINET OVERVIEW - ADVANCED

**ALARM TIMEOUT:** Time in seconds the alarm shall sound in case of an alarm

**ALARM OPEN DOOR:** The time the cabinet door can be open until the “open door alarm” will activate.

**MAIN ALARM ACTIVATED:** Possible to connect an external alarm to the cabinet so in case of an alarm, this relay will activate.

**MAIN ALARM FOR OPEN DOOR:** Time in seconds, after the first open door alarm is executed then the main alarm will be forwarded to the external alarm system.

**MAIN ALARM FOR NON\_ALLOWED KEY TAKEN:** Time in seconds from a key is taken unauthorized until the external alarm output will be activated.

**EXTERNAL LOCK:** Locks down the display, you need an input signal from an external device to unlock the display.

**PIN CODE CHANGE ALLOWED:** Allows users to change pin code in the cabinet.

**COMMENT:** Optional. Beware of your company’s GDPR policy when using comments.

**EDIT PAIRING CODE:** Change the pairing code of the cabinet.

**TIP:** To easily set time in seconds, pull the marker to left/right. If you point and hold the marker with left mouse click, you can also use the arrow keys on your keyboards to set second per second.

Edit cabinet

Basic Advanced

Alarm timeout (s)

1

Alarm timeout

1s

Alarm for open door

120s

☐ Main alarm activated

Main alarm for open door (s)

60s

Main alarm for non allowed key taken (s)

60s

☐ External lock

☐ Pincode change allowed

Comment

Edit pairing code (cabinet migration)

7B733E9E

Cancel Save

## SETTINGS – ADMINISTRATORS

---

Under **ADMINISTRATORS** you can add, remove, and edit staff that shall have access to KeyWin6 software.

Step 1: You add a new administrator by press on + and add the data below.

Step 2: once you have saved the initial data, you need to connect the admin to the cabinets.

- Name
- Last name
- Phone
- E-mail
- Cellphone
- Admin password (This is only for log in to keywin6 not cabinet.)
- Pin code (for super admin login to cabinet) this feature will only appear on the super administrator not on local administrators.


Then select what this administrator shall be able to see, change and do in KeyWin6 software

- Edit Users
- Edit Groups
- Edit Assets
- Edit Bookings
- Edit Administrators
- Edit cabinets
- Edit Settings

When you press **SAVE** you will also have to confirm  
Which cabinets these rights shall apply.

Beware of your company's GDPR policy when using comments field.

## Edit administrator



Name

Name that will be visible in the administration view

Firstname

Phone

Email

Cellphone

Pincode




[Generate PIN](#)

Rights

- ☐ Edit users
- ☐ Edit groups
- ☐ Edit assets
- ☐ Edit bookings
- ☐ Edit administrators
- ☐ Edit cabinets
- ☐ Edit settings

Available cabinets

Changes in this list will take effect immediately


Keybox 9600sc	
Förvaltning - Dörr 2	
500 - 1174	

KeyWin6 Manual – Version 1.0

## SETTINGS – ADMINISTRATORS

Once you saved the settings in step 1, in step 2 you shall connect your administrator to the cabinet(s) they should have access to edit.

## Edit administrator



Name

Robin

Name that will be visible in the administration view

Lasname

Storm

Phone

Email

Cellphone

Pincode

....

Generate PIN

Rights

☐ Edit users

☐ Edit groups

☐ Edit assets

☐ Edit bookings

☐ Edit administrators

☐ Edit cabinets

☐ Edit settings

Available cabinets

Changes in this list will take effect immediately

Keybox 9600sc


Förvaltning - Dörr 2

500 - 1234

Beware of your company's GDPR policy when using comments field.

## SETTINGS – Import/Export

In **Import/Export** you can import users via **XML** and export users and keys to a list.



When performing an export you will automatically be re-directed to a printer setup, press the printer symbol to print the file using your own printer setup or own .pdf printer etc.

Previous 1 2 3 Next 500 Users per page Back

Username	Firstname	Lastname	Email	Active	User type	Telephone	Cellphone	Service	Department	Valid from	Valid to
Adam	Adam	Bjellquist		true	Normal			sälj	creone	2018-01-17	9999-12-31
Musiker10	Dave10	Ghrol10		true	Normal	0140-386948		Musiker	Vocal	Invalid date	Invalid date
Musiker103	Dave103	Ghrol103		true	Normal	0140-387041		Musiker	Vocal	Invalid date	Invalid date
Musiker105	Dave105	Ghrol105		true	Normal	0140-387043		Musiker	Vocal	Invalid date	Invalid date
Musiker106	Dave106	Ghrol106		true	Normal	0140-387044		Musiker	Vocal	Invalid date	Invalid date
Musiker107	Dave107	Ghrol107		true	Normal	0140-387045		Musiker	Vocal	Invalid date	Invalid date
Musiker108	Dave108	Ghrol108		true	Normal	0140-387046		Musiker	Vocal	Invalid date	Invalid date

If you want to import users, you need to use an XML file. If you are not used to handle that format we have an Excel template with XML mappings already performed that you can download from our Help enter.

Username	Firstname	Lastname	PinCode	Active	UserType	Email	AllowUserChangePinCode	Service	Department	Telephone	Cellular	AuthCodes	Comment	Language
Import1	Import1	XML1	6550	SANT	0	import1@creone.com1	SANT	Importer	Export	0140-386190	0140-386190	123ABC11	test	sv
Import2	Import2	XML2	6551	SANT	0	import1@creone.com2	SANT	Importer	Export	0140-386191	0140-386191	123ABC12	test	sv
Import3	Import3	XML3	6552	SANT	0	import1@creone.com3	SANT	Importer	Export	0140-386192	0140-386192	123ABC13	test	sv
Import4	Import4	XML4	6553	SANT	0	import1@creone.com4	SANT	Importer	Export	0140-386193	0140-386193	123ABC14	test	sv
Import5	Import5	XML5	6554	SANT	0	import1@creone.com5	SANT	Importer	Export	0140-386194	0140-386194	123ABC15	test	sv
Import6	Import6	XML6	6555	SANT	0	import1@creone.com6	SANT	Importer	Export	0140-386195	0140-386195	123ABC16	test	sv
Import7	Import7	XML7	6556	SANT	0	import1@creone.com7	SANT	Importer	Export	0140-386196	0140-386196	123ABC17	test	sv
Import8	Import8	XML8	6557	SANT	0	import1@creone.com8	SANT	Importer	Export	0140-386197	0140-386197	123ABC18	test	sv
Import9	Import9	XML9	6558	SANT	0	import1@creone.com9	SANT	Importer	Export	0140-386198	0140-386198	123ABC19	test	sv
Import10	Import10	XML10	6559	SANT	0	import1@creone.com10	SANT	Importer	Export	0140-386199	0140-386199	123ABC20	test	sv
Import11	Import11	XML11	6560	SANT	0	import1@creone.com11	SANT	Importer	Export	0140-386200	0140-386200	123ABC21	test	sv

Helpcenter link: <https://creone.zendesk.com/hc/en-us/articles/360001343032>

## SETTINGS – ADVANCED SETTINGS

In **ADVANCED SETTINGS** you will be able to change your cabinets time zone, decide pin code structure and add, remove, and edit your card readers in the cabinet. This is settings that should be carried out by someone familiar to card reader programming and terminology.

When adding a new card reader, follow this procedure:

- Name** - The Name of the reader in the system
- Length** - The number of characters the reader shall show
- Baud rate** - Set the readers baud rate
- Start bit** -Set the readers start bit
- End bit** -Set the readers end bit

When all settings are completed, press” **Save settings**” and make a reboot on the cabinet. The new reader shall now exist in the configuration menu of the cabinet display.

Cabinet overview  
Administrators  
Import/Export  
**Advanced settings**  
Product information  
Creone  
Integrations  
Sntp  
Messages  
Notifications  
Other

Cabinet time zone

Asia/Saigon

Admin password

Minimum number of characters

4

Maximum number of characters

10

User pincode

Minimum number of characters

4

Maximum number of characters

10

Cardreader

Add cardreader

Name

Length

Baudrate

Starbit

Endbit

Add

Added cardreaders

Cidron 56bit - Hexadecimal

X

ACCESS 8 CPint - Hexadecimal

X

Creone Desfire - Hexadecimal

X

Creone - Hexadecimal

X

Reset settings

Save settings



## SETTINGS – PRODUCT INFORMATION

---

The setting and product information is to help Crone identify you and your installations when helping out with support issues.

Cabinet overview

Administrators

Import/Export

Advanced settings

Product information

Creone

Integrations

Smtp

Messages

Notifications

Other

---

Application and hardware

Product name

KeyWin 6

Software version

6.4.11

Release date: 2021-01-22

ID

c95576aa-f6b3-45e4-b97f-ea352fd77c62

License

Available until: 2029-02-05

☒ Booking module

☒ Report module

Retailer

Creone AB

Manufacturer

Creone AB

---

## SETTINGS – INTEGRATIONS

---

Creone can supply an integration engine and the API. Please note that Creone does reserve the rights to decide with whom and when we want to share our platform with.

For more information of INTEGRATIONS in KeyWin6, please contact Creone via e-mail;[support@creone.com](mailto:support@creone.com)

## SETTINGS – NOTIFICATIONS

Under NOTIFICATIONS you ADD the persons that shall receive alarms to e-mail.

To ADD a new recipient, press on +. You will then see the window as below.

Select the alarms this recipient shall receive:

- BoxOpenedToLongAlarm -
- DoorOpenedToLongAlarm -
- KeyInsertedInWrongPositionAlarm -
- KeyOutTooLongAlarm -
- KeyTakenByWrongUserAlarm -
- NonAllowedBoxOpenedAlarm -
- NonAllowedDoorOpenedAlarm -
- SyncError -

### Settings

- Cabinet overview
- Administrators
- Import/Export
- Advanced settings
- Product information
- Creone
- Integrations
- Smtip
- Notifications

### Recipients

Emails	Alarms
No recipients have been set	

When a recipient has been registered it will look as below. You can now send a “TestMail” to this recipient.

### Settings

- Cabinet overview
- Administrators
- Import/Export
- Advanced settings
- Product information
- Creone
- Integrations
- Smtip
- Notifications

### Recipients

Emails	Alarms	
robin.storm@creone.com	BoxOpenedToLongAlarm,DoorOpenedToLongAlarm	Send test mail

## SETTINGS – Other Settings

---

Under OTHER SETTINGS you can change if you want to see username in the display of the cabinet ore if you don't want to show the username.



Cabinet overview

Administrators

Import/Export

Advanced settings

Product information

Creone

Integrations

Smtp

Messages

Notifications

Other

### Other Settings

☐ Show userame on cabinet display